

LCD564ENC MOUNTING INSTRUCTIONS




Fig 1

To Surface mount (See Fig 1.)

The **LCD564** monitor must be compressed between the perspex window and the backplate or mounting surface.

Insert the protective **window** first, followed by the monitor, with self-adhesive spacers (as supplied) fixed to corners of rear panel of monitor.

The whole assembly is then screwed to the **mounting surface**.

To Flush mount (See Fig 2.)

First insert the enclosure into wall aperture, followed by the **LCD564** with self-adhesive spacers fixed to rear panel of monitor.

The protective **window** and front-plate follow.

The whole assembly is then screwed to the **mounting surface**.




Fig 2